


LIFTING SLIDER FRAME

1. Slide the ends of the lifting beam into the top clamps of the trestle leg and fully tighten.
2. Extend the telescopic leg inserts on the trestle legs to the desired height, insert height adjustment pins and tighten the thumb screws.
3. Fit the ends of the sway braces into the clamps on the top of the beam.
4. Swing the bottom ends of the sway braces out and using Lobands, clamp them to the trestle legs.
5. Check that the clamps in use are fully tightened.
6. Outriggers can be used to add extra stability, if necessary.

Outriggers can be fitted to improve stability

Lifting slider frame



SAFE WORKING LOAD
550lbs / 250kgs